

Installation with a Manual Slide Hammer

1. Ensure that all components are clean prior to use.
2. Cut the piezometer tubing to the depth of the proposed installation plus an additional 5 feet.
3. Connect the piezometer tubing to barbed fitting on the Drive Point Piezometer Tip by pushing firmly until the tubing reaches the base of the fitting.
4. Slide a length of extension drive pipe over the tubing, and thread it firmly onto the Drive Point Piezometer Tip. Tighten with a pipe wrench.


WARNING: When connecting or removing the Tubing Bypass, it is very important to hold the tubing to prevent it from turning. Failure to do so may result in the tube being dislodged from the Drive-Point Tip.

5. Hold the tubing to prevent it from turning, then slide the Tubing Bypass over the tubing and tighten it firmly onto the extension pipe, with the tubing extending through the side hole.
6. Thread a Drive Extension and the Drive Head onto the Tubing Bypass onto the Tubing Bypass and tighten firmly.
7. Thread the Drive Head onto the Drive Extension and tighten firmly.
8. Slide the Slide Hammer over the Drive Head and operate the hammer to drive the device until only about 6 inches of the extension pipe below the Tubing Bypass remains above the ground.
9. Hold the tubing to prevent it from turning, then remove all sections of the Drive Head Assembly.
10. Slide a coupling over the tubing and tighten firmly onto the previous extension pipe. Slide the next extension pipe over the tubing and tighten it securely.
11. Repeat steps 4 through 10 until the desired sampling depth is reached.
12. Cut the piezometer tubing to fit flush to the top of the extension pipe. Attach a cap to the top of the piezometer to complete the installation.

Component List

- Drive Point Piezometer Tip
- Extensions (suitable to reach the required depth)
- Couplings (one required for each extension)
- Manual Slide Hammer
- Piezometer tubing (suitable to reach the required depth)
- Drive Head Assembly (3 parts)

Includes: Drivehead, Drive Extension & Tubing Bypass
- Cap (101057)



Important Note about Shielded Piezometers

1. Before driving into the ground, ensure that the shield is on firmly and the o-ring seats properly.
2. Once the desired sampling depth is reached, retract the piezometer the length of the shield. At this time, sampling may commence.