

Mossback Block Adapter Assembly

*(for use with Root Wad, Safe Haven, Safe Haven XL,
Trophy Tree and Trophy Tree XL products)*

1. Place concrete block over base unit.
2. Place top plate over base unit pipe to rest on concrete block.
3. Slide trunk down over the base unit pipe. (Note: the Root Wad trunk will not fit flush with the top plate on block. Insert bottom limb first, hold trunk level, and insert 3 screws to secure)
4. Secure the trunk to the base unit pipe with three screws provided in pre-drilled holes.
5. Insert all limbs in trunk.

Do not place in swimming or boating areas. Check your local game laws.

See product assembly online at MossbackFishHabitat.com.

